

**S-TYPE**

DATE 09/02

S303-14

SERVICE**TECHNICAL BULLETIN****MIL Illuminated –
V6/V8 Engine Management Diagnosis –
Flowcharts**MODEL 2003 MY-ON
S-TYPE

VIN M45255-ON

Issue:


This bulletin provides diagnosis procedures for various components of the engine management system.

ENGINE MANAGEMENT SYSTEM FLOWCHARTS – TABLE OF CONTENTS


Flowchart Title

- P-1 Air Leakage (pages 2 and 3).
- P-2 Accelerator Pedal Position Sensor (pages 4, 5, 6 and 7).
- P-3 Camshaft Position Sensor (pages 8, 9, and 10).
- P-3a Additional Information (Camshaft Position Sensor) (pages 11 and 12).
- P-4 Crankshaft Position Sensor (pages 13, 14, 15 and 16).
- P-4a Additional Information (Crankshaft Position Sensor) (page 17).
- P-5 Engine Coolant Temperature Sensor (pages 18, 19 and 20).
- P-6 Engine Fuel Temperature Sensor (pages 21, 22 and 23).
- P-6a Engine Fuel Temperature Sensor Characteristics (page 24).
- P-7 V8 NA/SC Exhaust Gas Recirculation Valve (pages 25, 26, 27, 28 and 29).
- P-8 Upstream and Downstream Oxygen Sensor (pages 30, 31, 32, 33 and 34).
- P-8a Additional Information (Upstream and Downstream Oxygen Sensors) (page 35 and 36).
- P-9 V6/V8 NA Intake Air Temperature Sensor (pages 37, 38, 39 and 40).
- P-10 Injection Pressure Sensor (41, 42, 43, and 44).
- P-11 Knock Sensor (pages 45, 46 and 47).
- P-12 Mass Air Flow Sensor (pages 48, 49, 50, 51 and 52).
- P-13 Throttle Motor (pages 53, 54 and 55).
- P-14 V6/V8 NA Variable Valve Timing (pages 56, 57 and 58).
- P-15 Ignition Coil (pages 59, 60, 61, 61 and 63).
- P-15a Additional Information (Ignition Coil) (page 64).
- P-16 Throttle Position Sensor (pages 65, 66, 67 and 68).
Generic Connector Inspection (page 69).
Generic Harness Check (page 70).


Air Leakage Flowchart P-1




P-1 Cont.




Accelerator Pedal Position Sensor Flowchart P-2




P-2 Cont.




P-2 Cont.




P-2 Cont.




Camshaft Position Sensor Flowchart P-3



P-3 Cont.




P-3 Cont.



Additional Information P-3a

Oscilloscope set up.


- 1 Configuration sub tab.
Channel 1
Select: Red probe and black probe-Differential.
- 2 Channel calculation sub tab.
Select: Maximum voltage.
- 3 Main oscilloscope display sub tab.
Y-axis select: Scale set to 1 volt/div.
X-axis select: Scale set to 10 ms/div.
- 4 Select: Full screen.



J.100.223

Illustration 1 Trace of the camshaft position sensor at idle


P-3.a Cont.




J.100.224

Illustration 2 Trace of camshaft position sensor at 2000 rpm


Crankshaft Position Sensor Flowchart P-4




P-4 Cont.



P-4 Cont.




P-4 Cont.



Additional Information P-4.a

Oscilloscope set up.


- 1 Configuration sub tab.
Channel 1
Select: Red probe and black probe - Differential.
- 2 Channel calculation sub tab.
Select: Maximum voltage.
- 3 Main oscilloscope display sub tab.
Y-axis select: Scale set to 1 V/div.
X-axis select: Scale set to 10 ms/div.
- 4 Select: Full screen.




J.100.225

Illustration 3 Trace of the crankshaft position sensor at idle


Engine Coolant Temperature Sensor Flowchart P-5




P-5 Cont.




P-5 Cont.




Engine Fuel Temperature Sensor Flowchart P-6



P-6 Cont.



P-6 Cont.



Additional Information P-6.a
Engine Fuel Temperature Sensor Characteristics.

Temperature.	Nominal resistance Using DMM.	WDS Datalogger voltage display.
-10°C (14°F)	160.3 k-ohms ± 8.3 k-ohms	4.15 volts ± 0.04 v
10°C (50°F)	58.9 k-ohms ± 2.9 k-ohms	3.52 volts ± 0.06 v
20°C (68°F)	37.3 k-ohms ± 2.1 k-ohms	3.09 volts ± 0.07 v
30°C (86°F)	24.2 k-ohms ± 1.4 k-ohms	2.62 volts ± 0.07 v
40°C (104°F)	16.1 k-ohms ± 0.9 k-ohms s	2.15 volts ± 0.08 v

Abbreviations:


WDS - Worldwide Diagnostic System.

DMM - Digital Multi Meter.


Note: When testing the Engine Fuel Temperature sensor, if the vehicle is cold (approximately workshop temperature 20°C) it is possible to invoke a temperature change by rubbing the rail where the sensor is situated, this will increase the temperature and decrease the resistance.

WARNING: Parts may be hot.


V8 NA & SC Exhaust Gas Recirculation Valve Flowchart P-7




P-7 Cont.




P-7 Cont.




P-7 Cont.




P-7 Cont.




Upstream and Downstream Oxygen Sensor Flowchart P-8




P-8 Cont.




P-8 Cont.



P-8 Cont.



P-8 Cont.



Additional Information P-8.a

Subject - Upstream and downstream oxygen Sensors.

Checks.

- The upstream sensor is designated UHEGO and has a gray connector.
- The downstream sensor is designated HEGO and has a black connector.
- To ensure that the sensors are fitted correctly, the upstream sensor is situated directly above the catalytic converter (Pre- catalytic converter), and the downstream sensor is at the center of the catalytic converter.
- If the sensors are fitted vice versa this will cause catalytic converter monitor diagnostic trouble codes P0420 and P0430 to be logged.
- If the catalytic converter monitor DTCs are logged (P0420/P0430) and the orientation of the sensors is correct, then suspect catalytic converter failure. Remove the catalytic converter and visually check the honeycomb layout.
- Air leaks are possible at the connection of the sensor to the exhaust. Ensure the sensors are tightened to the correct torque.
- Problems may occur due to air leaks within the exhaust system.
- Carry out visual checks for cracks and leaks from the manifold down to the catalytic converter.
- Listen for the exhaust vapor escaping when cold, as it may not be noticeable as the exhaust warms and expands.

Cautions.

Removal. (Always refer to JTIS)

Ensure the connector on the fly lead is disconnected before removal.
Failure to do this may cause the wires to twist and damage or pull out of the sensor.


Installation. (Always refer to JTIS)

Over tightening may cause damage to the element within the sensor.
Ensure when fitting the sensor the correct tightening torque is used.
(Torque setting for both sensors 40 Nm +/- 7.2 Nm.)
Ensure the fly lead is routed correctly and is not taut, as this may cause damage with engine movement.


P-8.a Cont.

Additional Information			
Upstream oxygen sensor Diagnostic Trouble Codes		Downstream oxygen sensor Diagnostic Trouble Codes	
DTC	Description	DTC	Description
P0031	Heater control circuit low A	P0037	Heater control circuit low A
P0032	Heater control circuit high A	P0057	Heater control circuit low B
P0051	Heater control circuit low B	P0038	Heater control circuit high A
P0052	Heater control circuit high B	P0058	Heater control circuit high B
P0131	Circuit low voltage A	P0137	Circuit low voltage A
P0132	Circuit high voltage A	P0157	Circuit low voltage B
P0133	Circuit slow response 1A	P0138	Circuit high voltage A
P0151	Circuit low voltage B	P0158	Circuit high voltage B
P0152	Circuit high voltage B	P0140	Circuit no activity A
P0153	Circuit slow response 1B	P0160	Circuit no activity B
P1646	Control module open/shorted A		
P1647	Control module open/shorted B		
Refer to the DTC Summaries CD-ROM for further information.			


V6/V8 N/A Intake Air Temperature Sensor Flowchart P-9




P-9 Cont.




P-9 Cont.




P-9 Cont.




Injection Pressure Sensor Flowchart P-10




P-10 Cont.




P-10 Cont.




P-10 Cont.




Knock Sensor Flowchart P-11




P-11 Cont.




P-11 Cont.




Mass Air Flow Meter Flowchart P-12




P-12 Cont.




P-12 Cont.




P-12 Cont.




P-12 Cont.




Throttle Motor Flowchart P-13




P-13 Cont.




P-13 Cont.




**V6/V8 N/A Variable Valve Timing
Flowchart P-14**




P-14 Cont.




P-14 Cont.




Ignition Coil Flowchart P-15




P-15 Cont.




P-15 Cont.



P-15 Cont.



P-15 Cont.



Additional Information P-15.a

Related Diagnostic Trouble Codes.


P1367 Ignition amplifier group 1 malfunction
 P1368 Ignition amplifier group 2 malfunction
 P0351 to P0356 Ignition amplifier malfunction at the associated cylinder number 1 to 8
 P0300 Misfire random/multiple cylinders
 P0301 to P0306 Misfire at the associated cylinder number 1 to 8

Criteria.

All side 1 coils malfunction
 All side 2 coils malfunction
 Ignition coil open/short circuit/damaged harness on the associated cylinder
 Random misfire detected or misfires on 1 or more cylinder
 Misfire detected on the associated cylinder

Refer to the DTC Summaries CD-ROM for further information.


Side 1 of engine as indicated at 7 Fig. 4
 Side 2 of engine as indicated at 8 Fig. 4
 Front of engine as indicated at 9 Fig. 4



J.303.1704

Fig. 4 V6

Side 1 of engine as indicated at 10 Fig. 5
 Side 2 of engine as indicated at 11 Fig. 5
 Front of engine as indicated at 9 Fig. 5




J.303.1728


Fig. 5 V8

Always refer to the Technical Hotline if problems are encountered.


Throttle Position Sensor Flowchart P-16




P-16 Cont.



P-16 Cont.



P-16 Cont.



Generic Connector Inspection

Electrical failures can be caused by problems with the connectors and their pins. Below are a number of points that may aid in investigation.

Backed-out Pins

Inspection of the connector; look for signs that the pin has backed-out. If a seal is fitted to the pin it may be protruding further out the back of the connector. If a pin has backed-out of the cavity in the connector, there is a possibility that it has been forced out when the connector was mated. Make sure that the pins are in line when the two halves of the connector are mated.

Bent Pins

Disconnect the two halves of the connector and visually inspect the pins. If a pin is bent over there is a possibility of a short from pin to pin. Pins can easily be bent over when the connector is mated. Check to ensure the pins within the connector are not out of alignment before the two halves of the connector are mated.

Water ingress/fluid ingress

Disconnect the connector and inspect for signs of water ingress. Corrosion may have occurred. If water or any other fluid is visible this may cause a bad connection or even short circuit to the other pins within the connector. Examine the connector seals for any damage and to ensure that the seals are fitted correctly. Ensure that the two halves of the connector latch together securely.

Probing

Ensure when probing a pin that the correct probe is used and excessive force is not used as this may weaken the locating clip and allow the pin to work loose. Care must be taken when probing female pins as the pin can easily be splayed if probed with the incorrect adaptor or the wrong tool. This would then have the potential to cause a bad connection between the two mating halves. Always use the Worldwide Diagnostic System probe kit when probing pins within a connector. (Jaguar probe adaptor kit part number. 3548-1358-00.)

Insertion force

Insertion force is imperative to ensure a good connection is made between the two mating pins. If the female pin is splayed, the connection will be poor. To check the insertion force of the female connector, identify the correct male pin within WDS probe adaptor kit. Gently insert the adaptor into the female pin and then repeat with the other pins within the connector. If the pin in question feels loose in comparison replace both male and female pins.

Chafing

Inspect the harness when in close contact to other objects (i.e. sharp steel brackets). Engine vibration will cause the outer protection to quickly chafe through if the harness is not routed correctly. When performing a repair, ensure that heat resistant tape is used where relevant. Before repairing or renewing any harness, always refer to the Electrical Wiring Harness Repair Guide, reference publication number JTP 586. When repairing a harness ensure the Jaguar harness repair kit is used. (Part number. 418-S065 and 418-S411.)

Always refer to the Technical Hotline if problems are encountered.

Generic Harness Check

- When carrying out any of the tests in the generic harness check, it is imperative that any other sources that share the harness are taken into consideration when a measurement is taken.
- The S-TYPE Electrical Guide will show all other sources sharing that harness i.e. splices and sensors.
- Always ensure the digital voltmeter is operating correctly before proceeding.
- Always use the WDS probe kit when probing pins within a connector.

Note: Do not insert the Digital Multi Meter (DMM) leads into the connector pins. (Probe adaptor kit part number: 3548-1358-00.)

Continuity test

Using a DMM, connect the DMM to the pins at both ends of the circuit that you are testing. Ensure you connect to the correct pin when a large number of pins are used in a connector. (Use WDS Probe adapter kit).

Set the DMM to the resistance test or the continuity beeper. The resistance should be between 0 and 10 ohms. If a high resistance or open circuit is found investigate harness for damage.

Short circuit high fault

The DMM can be connected to any ground source on the vehicle, but it is preferable to use the battery negative pole.

Set the DMM to Volts DC; connect the DMM red probe to the suspect pin of the circuit and the DMM black probe to the battery negative pole. No voltage should be seen. If 4 – 13 volts is seen, suspect short circuit high and investigate harness for damage.

Always test the circuit with the ignition 'ON' and 'OFF' when trying to identify this fault condition.

Short circuit low fault (to ground)

The DMM can be connected to any ground source on the vehicle, but it is preferable to use the battery negative pole.

Set the DMM to the resistance test; connect the DMM to the suspect pin of the circuit and the battery negative pole. An infinity reading/open circuit (O/C) should be seen.

If a resistance is seen, suspect short circuit low and investigate harness for damage.

Always refer to the Technical Hotline if problems are encountered.