

---

<b>Reference</b>	SSM70338
------------------	----------

---

<b>Models</b>	F-TYPE / X152 XF / X250 XJ / X351 XK / X150
---------------	--

---

<b>Title</b>	Rear tow eye - all models
--------------	---------------------------

---

<b>Category</b>	Chassis
-----------------	---------

---

<b>Last modified</b>	10-Dec-2013 00:00:00
----------------------	----------------------

---

<b>Symptom</b>	307000 Jack/Tool & Spare
----------------	--------------------------

---

<b>Content</b>	<p><u>Issue:</u> Rear tow eye / transport lashing, causing potential damage to longitudinal chassis members.</p> <p><u>Cause:</u> Rear transport tow eye being left in place or not discarded at PDI as per check sheet.</p> <p><u>Action:</u> Please ensure that as per the relevant PDI check sheet on TOPIX, rear transport / lashing eyes / fixings are discarded at PDI, whilst ensuring the front one is added into the vehicle tool kit. Damage to the chassis can occur if the transport fixing for the rear is used to tow other vehicles.</p>
----------------	---