Operator Action

Make connections as shown.

- · Connect the VMM cable to the PC USB port.
- · Connect the VMY cable to the Vehicle battery.
- · Set ignition switch to ON (Position II).

Press tick to continue

the vehicle pedals Warning: The diagnostic cables must not interfere with the safe operation of the vehicle. Secure all cables away from





