

Press the Floppy disc “IN” icon to save the VID capture file. Ensure that the PTU is “docked”, with power and that a disc is inserted into the “A” drive. The WDS should display that the save has been completed successfully.

The VID Block file is now ready to E-mailed to the dealer technical helpline.