

Exterior Lighting - Rear Fog Lamp

Removal and Installation

Removal



CAUTION: Take precautions to avoid any electrostatic charging, which could damage this component.

NOTES:



Some variation in the illustrations may occur, but the essential information is always correct.



Removal steps in this procedure may contain installation details.

1. Refer to: [Battery Disconnect and Connect](#) (414-01 Battery, Mounting and Cables, General Procedures).

2.



WARNING: Make sure to support the vehicle with axle stands.


Raise and support the vehicle.

3.




NOTE: The step must be carried out on both sides.

Torque: 4 Nm



V6



V8

E153514

Installation

1. To install, reverse the removal procedure.