

Wiring Information

Item	Wire Color	Polarity	Wire Location
12 Volts	gray (50A)	+	passenger footwell fuse box, green 41 pin plug, pin 22
Second 12 Volts	N/A		, , , , , , , , , , , , , , , , , , ,
Starter	brown/purple (SS1); yellow/orange (SS2)	- 250 ohms	start/stop sw or pass footwell fuse box, gray 28 pin plug, pins 18, 17
Second Starter	blue/white	+	passenger footwell fuse box, rear, green 32 pin plug, pin 18
Ignition	yellow (for ignition sense only)	+	passenger footwell fuse box, green 41 pin plug, pin 10
Second Ignition	N/A		
Third Ignition	N/A		
Accessory	green/white (for accessory sense only)	+	center acc socket or pass footwell fuse box, blue 46 pin plug, pin 30
Second Accessory	N/A		
Third Accessory	N/A		
Key Sense	N/A		
Data Bus	purple/white (LIN bus)	data	Immobilizer Antenna Module on driver dash, green 3 pin plug, pin 2
Can Bus High	gray/orange (MS CAN); white/blue (HS CAN)	data	data link connector, black 16 pin plug, pins 3, 6
Can Bus Low	purple/orange (MS CAN); white (HS CAN)	data	data link connector, black 16 pin plug, pins 11, 14
Can Bus Sw	N/A		
Power Lock	gray/brown	-	passenger footwell fuse box, gray 28 pin plug, pin 9
Power Unlock	brown/green	-	passenger footwell fuse box, gray 28 pin plug, pin 8
Lock Motor	black	5 wire	Driver Door Module, black 22 pin plug, pin 10
Unlock Motor	black	5 wire	Driver Door Module, black 22 pin plug, pin 7
Disarm Defeat	black	5 wire	Passenger Door Module, gray 22 pin plug, pin 7
Parking Lights (+)	green (LF); grn/wht (RF); grn/og (LR); brn/ye (RR)	+	passenger footwell fuse box, brown 46 pin plug, pins 12, 1, 2, 38
Parking Lights (-)	yellow/blue (need to relay isolate from switch)	- 236 ohms	headlight sw or pass footwell fuse box, rear, gray 32 pin plug, pin 20
Hazards	brown/yellow	-	hazard sw or passenger footwell fuse box, gray 28 pin plug, pin 19
Turn Signal (Left)	blue/green (F); gray/orange (R)	+	passenger footwell FB, grn 41 pin plug, pin 32; brn 46 pin plug, pin 9
Turn Signal (Right)	yellow/purple (F); green/orange (R)	+	passenger footwell FB, grn 41 pin plug, pin 37; brn 46 pin plg, pin 10

Wiring Information (Continued)

•		
Wire Color	Polarity	Wire Location
yellow/blue (need to relay isolate from switch)	- 506 ohms	headlight sw or pass footwell fuse box, rear, gray 32 pin plug, pin 20
yellow/blue (need to relay isolate from switch)	-56ohm(off	sw or pass footwell FB, rear, gray 32P plg, pin 20
green/white	+	passenger footwell fuse box, brown 46 pin plug, pin 40
gray/purple	-	passenger footwell fuse box, rear, brown 32 pin plug, pin 11
white	-	pass footwell FB, rear, brown 32 pin plug, pin 12
N/A		
N/A		
gray/purple	+	footwell lamp or pass footwell fuse box, blue 46 pin plug, pin 2
yellow/orange	-	passenger footwell fuse box, rear, brown 32 pin plug, pin 23
N/A		
blue/orange	-	passenger footwell fuse box, rear, green 32 pin plug, pin 5
white	-	release sw or pass footwell fuse box, rear, gray 32 pin plug, pin 14
black	5 wire	passenger footwell fuse box, brown 46 pin plug, pin 6
white/purple (unlock only)	5 wire	passenger footwell fuse box, brown 46 pin plug, pin 32
N/A		
N/A		
(arms on lock with door open)		
(see disarm no unlock)		
(smart key and push-button start)		
N/A		
ye/bu, bu/og, gn/pu, bu, wh/gn, bn/pu, bu/wh, wh/o	ac	any fuel injector, black 2 pin plug, pin 2
N/A		
N/A		
N/A		
purple/green	-	pass footwell FB, rear, green 32 pin plug, pin 13
brown/blue	+ latched	passenger footwell fuse box, brown 46 pin plug, pin 23
(MS CAN, mirrors); purple/orange (windshield)	- latched	passenger footwell fuse box, rear, green 32 pin plug, pin 29
(LIN bus)		
(LIN bus)		
	yellow/blue (need to relay isolate from switch) yellow/blue (need to relay isolate from switch) green/white gray/purple white N/A N/A N/A gray/purple yellow/orange N/A blue/orange white black white/purple (unlock only) N/A N/A N/A (arms on lock with door open) (see disarm no unlock) (smart key and push-button start) N/A ye/bu, bu/og, gn/pu, bu, wh/gn, bn/pu, bu/wh, wh/o N/A N/A purple/green brown/blue (MS CAN, mirrors); purple/orange (windshield) (LIN bus)	yellow/blue (need to relay isolate from switch) yellow/blue (need to relay isolate from switch) yellow/blue (need to relay isolate from switch) green/white + gray/purple - white - N/A N/A N/A Syellow/orange - white - black 5 wire white/purple (unlock only) 5 wire N/A N/A N/A N/A N/A N/A N/A N/

Wiring Information (Continued)

	(Oortanded)		
Item	Wire Color	Poli y	arit Wire Location
Speed Sense	(wheel speed sensor)		
Brake Wire	purple/brown	+	brake sw or passenger footwell fuse box, rear, brown 32 pin plug, pin 6
Parking Brake	(electric parking brake)		
Horn Trigger	blue/white	1	horn sw or passenger footwell fuse box, rear, green 32 pin plg, pin 28
Wipers	purple/white	-	passenger footwell fuse box, rear, green 32 pin plug, pin 25
Left Front Window (Up/Down)	(not recommended because of factory auto up/down)		
Right Front Window (Up/Down)	(not recommended because of factory auto up/down)		
Left Rear Window (Up/Down)	N/A		
Right Rear Window (Up/Down)	N/A		
Sun Roof (Open/Close)	green/purple - blue/orange (func with ign on only)	-	folding top switch, black 8 pin plug, pins 3 - 5
Sun Roof (Limit/Close)	N/A		
Memory Seat 1	(LIN bus)		
Memory Seat 2	(LIN bus)		
Memory Seat 3	(LIN bus)		
Radio 12V	yellow	+	radio in rear of center console, gray 14 pin plug, pin 1
Radio Ground	black/white	1	radio in rear of center console, gray 14 pin plug, pin 8
Radio Ignition	(MOST bus)		
Radio Illumination	N/A		
Factory Amp Turn-on	(MOST bus)		
Power Antenna	yellow/orange	+	radio in rear of center console, gray 14 pin plug, pin 2
Left Front Speaker (+/-)	wht-wh/bn (lo); gn/bu-gy/bu (md); gn/og-gy/og (hi)	+,-	amplifier between seatbacks, gray 16 pin plug, pins 2-10; 5-13; 1-9
Right Front Speaker (+/-)	wh/pu-wh/og (lo); pu/gy-ye/gy(md); pu/og-ye/og(hi)	+,-	amplifier between seatbacks, gray 16 pin plug, pins 4-12; 7-15; 3-11
Left Rear Speaker (+/-)	white/green - brown/yellow	+,-	amplifier between seatbacks, gray 16 pin plug, pins 6 - 14
Right Rear Speaker (+/-)	brown/white - brown/blue	+,-	amplifier between seatbacks, gray 16 pin plug, pins 8 - 16
Center Channel (+/-)	white/blue - green/orange	+,-	amplifier between seatbacks, blue 16 pin plug, pins 7 - 15
Subwoofer (+/-)	green/pur - gray (L CH1); white - blue/grn (L CH2)	+,-	amplifier between seatbacks, blue 16 pin plug, pins 3 - 11; 1 - 9
Aux. Audio Input Left (+/-)	blue - yellow/green	+,-	radio in rear of center console, gray 14 pin plug, pins 5 - 7
Aux. Audio Input Right (+/-)	blue/green - yellow/green	+,-	radio, gray 14 pin plug, pins 6 - 7
RSE Video (+/-)	(coaxial cable)		
RSE Audio Left (+/-)	(MOST bus)		
RSE Audio Right (+/-)	(MOST bus)		
Satellite Radio 12 Volts	purple	+	sat radio between seatbacks, grn 4 pin plug, pin 1
Satellite Radio Ground	black/green	-	sat radio between seatbacks, grn 4 pin plug, pin 4
Satellite Radio Ignition	(MOST bus)		
Satellite Radio Antenna	(coaxial cable)		