


The XK only



JCL3496



1. ON/OFF switch and volume control.
2. Mode.
3. Phone send/end calls.
4. Phone memory recall button.
5. Phone keypad - buttons 0 to 9.
6. Phone clear.
7. Display.
8. Phone mode button.

'Pairing' Your Phone

Before use, your mobile phone must be connected or 'paired' with the vehicle's Bluetooth system.

Vehicles with touch-screen

Follow these steps to pair your phone with the vehicle:



- Switch the vehicle's ignition ON (position II).
- Press the  button, to the left of the touch-screen.
- Using the touch-screen keypad, enter the code '##1#*#', then touch .
- The message 'Discover Me' will be displayed, to confirm that the system is ready to pair with a mobile phone.
- Switch on your mobile phone's Bluetooth connection, using the phone's menu. (See your phone's manual for more information).
- Select 'search for other Bluetooth devices' or 'Audio Accessories' from your mobile phone's menu.
- Select 'Jaguar' in your phone's paired device list, in order to connect to the vehicle's Bluetooth system.
- Enter the Passkey on your mobile phone (the Passkey is 1313).
- Under certain circumstances, the message 'No BT Phone' may be displayed briefly.
- After a short delay, the message 'Phone Connected' will confirm that the phone and vehicle are paired.

Note:

- Once a mobile phone has been paired with the vehicle, the system will look for the same phone each time the ignition is switched ON. If no phone is detected, the message 'No BT Phone' will appear on the touch-screen to confirm that no phone is connected after approximately three minutes.
- When a mobile phone is paired to the vehicle and the Bluetooth connection is established, one bar will be displayed next to the antenna icon. However, you will need to refer to your mobile phone's display to determine the strength of the network signal.
- If an incorrect Passkey is entered, your mobile phone should prompt you to enter the correct Passkey.
- If there is a delay of approximately five minutes when pairing a phone with the vehicle, a screen with the message 'Handset In Use' may be displayed. If this occurs, switch the vehicle ignition to OFF and wait for at least five minutes before repeating the pairing procedure.

Vehicles without touch-screen

Follow these steps to pair your phone with the vehicle:

- Switch the vehicle's ignition ON (position II).
- Press the  button on the audio panel. 'SIG' will be displayed.
- Using the audio panel keypad, enter the code '##1##' and press the  button.
- 'SIG****' will be displayed.
- Switch on your mobile phone's Bluetooth connection, using the phone's menu. (See your phone's manual for more information).
- Select 'search for other Bluetooth devices' or 'Audio Accessories' from your mobile phone's menu.
- Select 'Jaguar' in your phone's paired device list, in order to connect to the vehicle's Bluetooth system.
- Enter the Passkey on your mobile phone (the Passkey is 1313). 'SIG' will be displayed initially.
- Once the vehicle and phone are paired, 'SIG *' will appear on the audio panel.

Note:

- Once a mobile phone is paired with the vehicle, 'SIG*****' will be displayed initially when the ignition is switched ON. If no phone is detected, the message 'SIG' will confirm that no phone is connected after approximately two minutes.
- If an incorrect Passkey is entered, your mobile phone should prompt you to enter the correct Passkey.

All vehicles

Once a mobile phone is paired with the vehicle, the vehicle will look for this specific phone every time the ignition is switched ON.

Pairing other phones



Only one mobile phone can be paired with the vehicle at a time. Once paired, the vehicle will look for the same phone each time the ignition is switched ON (position II): you do not need to manually pair the phone with the vehicle every time you switch the ignition ON.

The Bluetooth function of your mobile phone must be switched on when the ignition is switched ON in order for it to pair with the vehicle automatically.

If a different Bluetooth mobile phone is to be used with the vehicle, it must be paired manually, as described previously. This phone will then become the 'default' phone, which the system will look for each time the ignition is switched ON.

Disconnecting a phone

To disconnect a mobile phone from the system:



- Press the  button on the audio panel or touch-screen.
- Enter '##3##' on the keypad, and press the  button.

A mobile phone can also be disconnected via the mobile phone's keypad. Refer to your phone's manual for more details.

Phone Book Transfers

Any phone numbers stored in your mobile phone book can be copied to the vehicle's phone system.

In most cases, this will happen automatically when you pair the phone with the vehicle. However, with some mobile phones, you may need to manually transfer the phone book.

- Make sure the vehicle ignition is ON and the vehicle and phone are paired.
- Press the  button on the audio panel or touch-screen surround.
- Enter '##2##' on the audio panel or touch-screen keypad, and press the  button.

The system will only store transferred numbers while the ignition is ON. In most cases, the phone book will be transferred each time the vehicle and phone are paired. If a different phone is paired with the vehicle, the original phone book will be cleared, and the phone book from the new phone will be transferred instead.

Note: It may take several minutes to copy the phone book to the vehicle, depending on the number of entries stored in the phone. Depending on the type of mobile phone used, the system may not be operational during this period.

'Silent' Mode

Certain mobile phones have a 'Silent' mode or profile, which prevents the handset from ringing when a call is received.

If the mobile phone is set to 'Silent', it will also prevent the vehicle phone system from ringing.

Pairing Your Phone

(Vehicles without touch-screen)

The description of how to pair your phone with the vehicle has changed. See page 12 of the Bluetooth Telephone Handbook.

It is recommended to use the code **##3##** to pair your phone because this code has no automatic time-out period.


However, if the code **##1##** is entered it will still work correctly, but the system automatically times-out after approximately five minutes. A delay longer than this when pairing a phone with the vehicle will cause the audio system to exit phone mode and revert to its previous audio mode. If this occurs, switch the vehicle ignition OFF and wait for at least six minutes before repeating the pairing procedure.

Once a mobile phone is paired with the vehicle, **'SIG'** will be displayed initially when the ignition is switched ON. **'SIG'** will then be displayed, once the phone is detected.

If the phone is not detected within two minutes, the audio system will exit phone mode and revert to its previous audio mode.

Rejecting a Call

(The XJ, X-TYPE and S-TYPE)



Press **CANCEL** on the audio panel to reject an incoming call.

(The XK only)



Press **C/TA** on the audio panel to reject an incoming call.

Last Number Redial

(The XK only)



Press and hold the send/end button on the audio panel to recall the last number dialled. See page 21 of the Bluetooth Telephone Handbook for more information.

Searching by Name

(Vehicles with touch-screen)

It is possible to list names stored in the vehicle phone book, whilst the vehicle is in motion (see page 23 of the Bluetooth Telephone Handbook).



WARNING:

Jaguar recommends that the driver does not use this feature whilst the vehicle is in motion. Give full attention to driving - safe driving is your first responsibility.