



### Exterior Mirror 76.10.52

#### Removal


1. Remove the front door interior trim panel. For additional information refer to <<501-05>>



2. Disconnect the rear view mirror electrical connector.




3. Detach the window frame interior trim.



VUJ0000734

4. Remove the rear view mirror screw covers.



VUJ0000735

5. **NOTE:**

Support the mirror while removing retaining screws.

Remove the rear view mirror.

### Installation

1. To install, reverse the removal procedure.