


Locally detach the door aperture weatherstrip.

4 . Detach the C-pillar trim panel.



5 . Remove the C-pillar trim panel.

▶ Cut the C-pillar trim panel retaining strap.

