



**Front Door Trim Panel 76.34.01**

**Removal**




VUJ0000707

1. Remove the front door interior handle bezel.




VUJ0000709

2. Remove the front door trim panel retaining screw cover.



VUJ0000710


3. Remove the front door trim panel retaining screws.




VUJ0000711

4. Detach the front door door trim panel.

- To aid removal release clip A by lowering the glass and pressing the panel inward.



5. Disconnect the front door trim panel harness electrical connector.



6. Remove the front door trim panel.  
• Disconnect the driver door module electrical connector.

### Installation

1. To install, reverse the removal procedure.