



**Exterior Mirror Glass 76.10.53**

**Removal**



VUJ0003101


1. Apply light pressure to the exterior mirror glass.



VUJ0003435

- 2. Detach the exterior mirror glass.
- 1. Apply light pressure to the inner edge of the exterior mirror glass.
- 2. Detach the exterior mirror glass.

## 2003 S-TYPE - Rear View Mirrors - 501-09



3. Remove the exterior mirror glass.
  - Disconnect the electrical connectors.

### Installation

1. To install, reverse the removal procedure.