


Radiator Splash Shield 76.22.90

Removal

1. Raise and support the vehicle. For additional information, refer to<<100-02>>.



2. Remove undertray assembly.

Installation

1. To install, reverse the removal procedure.