

R9
SLAVE IGNITION
RELAY*

STARTER
RELAY

R11
POWER WASH
RELAY
EMS CONTROL
RELAY

R12
THROTTLE MOTOR
RELAY

RH
WINDSHIELD
HEATER RELAY
HEATED
WIPER PARK
RELAY

R13
R14
HORN
RELAY

F1 Front Ignition, UHEGO, Fuel Pump,
rear Ignition Relay Coils.

F4 Power wash Pump

F6 Air Suspension Compressor

F7 Right-hand Front Screen Heater /
Wiper Park Zone heater

F8 Right Low Beam

F9 Left Low Beam

F12 Engine Control Module

F13 Fuel Injectors

F14 Purge Valve, EGR Valve, CCV
(valve), Port deactivation, IMTV, MAFS,
Air filter Solenoid, Radiator Fan
Controller.

F16 Both High beams

F17 Engine Control Module

F18 Front Fog Lights, Instrument Cluster
Fog Status.

F19 Starter Solenoid

F20 ABS Module (Pump)

F22 ABS Module

F24 Throttle Motor

F25 Horns

F26 Wiper System, Front
Electronics Module (FEM)


F30 Ignition Coils

F31 Intercooler Water Pump (SC)


F32 Left-hand Front Screen Heater

F33 "A" Bank Heated Oxygen
Sensors


F34 "B" Bank Heated Oxygen
Sensors



FRONT POWER DISTRIBUTION FUSE BOX



PASSENGER JUNCTION FUSE BOX



REAR POWER DISTRIBUTION FUSE BOX