2010.0 X351, 501-14

HANDLES, LOCKS, LATCHES AND ENTRY SYSTEMS

EXTERIOR FRONT DOOR HANDLE (G1267533)

REMOVAL AND INSTALLATION

FRONT
76.58.01 DOOR ALL USED
HANDLE - DERIVATIVES 0.1 WITHINS
RENEW

REMOVAL


\triangle NOTES:

- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.

. | ,


\triangle NOTE:

Remove the screw sufficiently, only to release the component.



Torque: 4 Nm

2.




3. ① CAUTION:


Take extra care not to damage the wiring harnesses.

△ NOTE:

Secure the connection in the service position.



4




INSTALLATION

1.

① CAUTION:

Make sure that the wiring harnesses are correctly located.



To install, reverse the removal procedure.