

Maintenance must be carried out at intervals not to exceed 16,000 miles or one year, whichever occurs first. Should the vehicle have a high proportion of short journeys or operate in severe conditions, Jaguar North America recommends that the maintenance procedures be performed at intervals not to exceed six months.

SERVICE	Interval: Miles x 1,000	16	32	48	64	80	96	112	128	144	160
	Interval: Years	1	2	3	4	5	6	7	8	9	10
Check function of all exterior lights, horn, and warning lights		•	•	•	•	•	•	•	•	•	•
Inspect wiper blades for wear; check wiper operation		•	•	•	•	•	•	•	•	•	•
Check / top up brake fluid level		•	•	•	•	•	•	•	•	•	•
Check coolant protection / top up coolant level		•	•	•	•	•	•	•	•	•	•
Check / top up power assisted steering fluid level		•	•	•	•	•	•	•	•	•	•
Check / top up windshield washer fluid level		•	•	•	•	•	•	•	•	•	•
Check / top up battery electrolyte level			•		•		•		•		•
Visually check under hood and under body for any fluid leaks		•	•	•	•	•	•	•	•	•	•
Inspect brake pads for wear; check rotor condition when pads are changed		•	•	•	•	•	•	•	•	•	•
Check tires (including spare tire): – pressure, tread depth and general condition – signs of uneven wear – correct size and type		•	•	•	•	•	•	•	•	•	•

SERVICE	Interval: Miles x 1,000	16	32	48	64	80	96	112	128	144	160
	Interval: Years	1	2	3	4	5	6	7	8	9	10
Verify electronic parking brake operation		•	•	•	•	•	•	•	•	•	•
Replace engine oil and oil filter		•	•	•	•	•	•	•	•	•	•
Replace climate controlled seat cushion motor filters (if equipped)			•		•		•		•		•
Replace pollen filter			•		•		•		•		•
Replace air filter element: Normally Aspirated					•				•		
Replace air filter element: Supercharged				•			•			•	
Replace brake fluid		Every 3 years regardless of mileage									
Replace spark plugs		Every 6 years or 96,000 miles									
Replace supercharger drive belt		Every 6 years or 96,000 miles									
Replace accessory drive belt		Every 9 years or 144,000 miles									
Replace engine coolant		Every 9 years or 160,000 miles									
Conduct road test		•	•	•	•	•	•	•	•	•	•
Reset Service Indicator		•	•	•	•	•	•	•	•	•	•
Reset Engine Oil Level Indicator		•	•	•	•	•	•	•	•	•	•
Endorse Service Record		•	•	•	•	•	•	•	•	•	•
Check for any applicable outstanding Service Actions or Recalls		•	•	•	•	•	•	•	•	•	•