

This is how the oil is checked in "Live Mode."

This works like a charm.

1. Open the Hood
2. Get in the car with the key-fob and close the doors
3. Push start button without touching the brake
4. Let all the electronics settle down and then use the Menu/OK button on the left side of the steering wheel...navigate around until you get the "Vehicle Information" screen..
5. Select "Oil Level". If it says "information not available"...Press the cruise control "Cancel" button twice. The Oil Level will then be displayed.

NOTE: 1/4 of a qt from full = about half way down the meter