



**Fig. 70 Schematic of fuel tank internals - normally aspirated application**

- |  |  |
|--|--|
| 1. Fuel pump and fuel level sensor, electrical connector | 9. Fuel level sensor, electrical connector   |
| 2. Fuel pump module                                      | 10. High-pressure crossover circulation line |
| 3. Suction jet-pump                                      | 11. Low-pressure crossover circulation line  |
| 4. Fuel pump   | 12. Engine fuel-delivery line                |
| 5. Right-hand fuel compartment                           | 13. Fuel filter                              |
| 6. Left-hand fuel compartment                            | 14. Fuel rail                                |
| 7. Fuel level sensor                                     | 15. Fuel injector                            |
| 8. Parallel pressure relief valve                        |  |