



Rear Seat Backrest 76.70.38

Removal

1. Remove the rear seat cushion. <<Rear Seat Cushion - >>



2. Fully extend the rear center safety belt.




3. **NOTE:**
Right-hand shown, left-hand similar.

Detach the rear seat backrest.

2004 XJ RANGE - Seating - 501-10

1. Release the rear seat backrest retaining clip.
2. Detach the rear seat backrest.



E39440

4. Remove the rear seat backrest.

Installation

1. **NOTE:**

Make sure the rear seat backrest pivot bracket inserts are correctly installed.

NOTE:

Install new rear seat backrest pivot bracket inserts if they are damaged.

To install, reverse the removal procedure.