

R9  
SLAVE IGNITION  
RELAY\*

STARTER  
RELAY

R11  
POWER WASH  
RELAY  
EMS CONTROL  
RELAY


R12  
THROTTLE MOTOR  
RELAY

RH  
WINDSHIELD  
WIPER RELAY


R13  
HEATED  
WIPER PARK  
RELAY

R14  
HORN  
RELAY


AIR SUSPENSION RELAY



FRONT POWER DISTRIBUTION FUSE BOX



**PASSENGER JUNCTION FUSE BOX**



**REAR POWER DISTRIBUTION FUSE BOX**