



Item	Part Number	Description
1		Transmission oil cooler inlet
2		Engine coolant outlet
3		Vent hose
4		Auxiliary coolant flow pump
5		Сар
6		Fan harness connector
7		Expansion tank
8		Heater return pipe
9		Heater feed pipe
10		Bleed screw
11		Engine oil cooler connections
12		Transmission oil cooler outlet