°1230		Fuel pump relay malfunction NOTE: This DTC covers the N/A system single fuel pump and the SC system fuel pump 1.	Ignition OFF; Ignition ON > 5 seconds	2	N/A: N SC: 2 [A, M]	N/A - None SC - When fault is detected, ECM: - Operates fuel pump 2	EM83 -04	Fuel pump relay failure Fuel pump relay to ECM circuit fault Fuel pump relay coil power supply open circuit ECM ground circuit fault (relay coil drive)	
-------	--	---	---------------------------------------	---	---------------------------	--	-------------	--	--