

Vehicle:
Customer:
Operator:
Date(D/M/Y):21/05/2022

=====
JAGUAR_EN_TEST_00002>XJ>1998>Smart Scan>TCM (Transmission control module)>Read
Fault Code:
Total Number : 1

P0706 1/1
State: Current
Transmission range sensor circuit range/performance.

=====
JAGUAR_EN_TEST_00002>XJ>1998>Smart Scan>IP (Instrument pack)>Read Fault Code:
Total Number : 2

B1202 1/2
State: Current
Fuel sender: circuit open.

B1317 2/2
State: Current
Battery voltage high.

=====
JAGUAR_EN_TEST_00002>XJ>1998>Smart Scan>SLM (Security locking module)>Read Fault
Code:
Total Number : 1

U1135 1/1
State: Current
Ignition state not obtained

=====
JAGUAR_EN_TEST_00002>XJ>1998>Smart Scan>BPM (Body processor module)>Read Fault
Code:

Total Number : 10

B2334 1/10
State: Current
Column drive, tilt out of range high.

B2330 2/10
State: Current
Column drive, reach out of range high.

U1041 3/10
State: Current
SCP vehicle speed signal - invalid or missing message.

B1595 4/10
State: Current
Ignition switch - illegal input code

B1794 5/10
State: Current
Headlamp switch active with side lamp switch inactive

U2012 6/10
State: Current
Communication bus error - non SCP.

B1352 7/10
State: Current
Key-in circuit failure.

B1446 8/10
State: Current
Wiper park sense - circuit failure

B2368 9/10
State: Current
Column adjust switch, out of range

B1875 10/10
State: Current
Turn signal switch left and right switches active.

=====
JAGUAR_EN_TEST_00002>XJ>1998>Smart Scan>DRDM (Driver's (Side) rear door
module)>Read Fault Code:
Total Number : 1

U1135 1/1
State: Current
Ignition state not obtained

=====
JAGUAR_EN_TEST_00002>XJ>1998>Smart Scan>PDM (Passenger's door module)>Read Fault
Code:
Total Number : 1

U1135 1/1
State: Current
Ignition state not obtained

=====
JAGUAR_EN_TEST_00002>XJ>1998>Smart Scan>PRDM (Passenger's (Side) rear door
module)>Read Fault Code:
Total Number : 1

U1135 1/1
State: Current
Ignition state not obtained