


# ELECTRICAL FAULT DIAGNOSIS

## KEY TO DIAGRAM

1. Battery
2. Alternator
3. Warning light
4. Ignition switch
5. To fuse No 12
6. Automatic gearbox safety switch
7. Ignition protection relay
8. To tachometer
9. Main HT coil
10. Auxiliary coil
11. Starter relay
12. Amplifier
13. Distributor
14. To ECU
15. Starter motor
16. To ECU

## IGNITION, ALTERNATOR AND STARTER SYSTEMS



1 To check the switching circuit for high | Test 3