FIG 6 DATA

COMPONENTS

DESCRIPTION

BULB FAILURE UNIT - STOP LIGHT DIODE - RHD1

FLASHER UNIT
HAZARD SWITCH *
LIGHTING AND TURN SIGNAL SWITCH PARKING BRAKE SWITCH RELAY - STOP LIGHT (RH113) STOP LIGHT SWITCH

LEFT REAR WHEEL ARCH
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT
LEFT COMPONENT PANEL
LEFT OF TRIP COMPUTER
STEERING COLUMN, LEFT
PARKING BRAKE HANDLE

LEFT REAR TRUNK TRIM LEFT TRUNK TRIM LEFT UNDER DASH PANEL

REMOVE STEERING COLUMN TRIM REMOVE BRAKE HANDLE TRIM LEFT TRUNK TRIM PANEL LEFT UNDER DASH PANEL

FARMING BRAKE TRINDLE TRINDER TRINDLE TRINDLE

CONNECTORS

DESCRIPTION CH17 CS1 16-WAY SUMITOMO BLOCK (WHITE) 20-WAY SUMITOMO BLOCK (WHITE) 16-WAY SUMITOMO BLOCK (WHITE)
250 BLADE (WHITE)
3-WAY PM 5 (BLACK)
4-WAY PM 5 (BLACK)
4-WAY SUMITOMO STD. (RED)
RELAY BASE (YELLOW)
10-WAY MULTILOCK 70 (WHITE)
16-WAY SUMITOMO BLOCK (RED)
2-WAY SUMITOMO BTD. (SLATE)
2-WAY SUMITOMO STD. (SLATE)
2-WAY SUMITOMO STD. (WHITE)
RELAY BASE (YELLOW)
4-WAY SUMITOMO STD. (WHITE)
RELAY BASE (YELLOW)
4-WAY SUMITOMO STD. (WHITE)
250 BLADE (BLACK)
250 BLADE (BLACK)
250 BLADE (BLACK)
24-WAY SUMITOMO BLOCK (WHITE)
20-WAY SUMITOMO BLOCK (WHITE) CS7 CS8 CS9 HL1 HL2 LB167 LB172 LB176 LF1 LF24 LF31 RF1 RH96 RH113 RH119 RH127 RH128 RH129 RH160 RH161

LOCATION / INTERFACE

LOCATION / INTERFACE
BELOW RIGHT A/C OUTLET / CENTER HARNESS
ADJACENT TO STEERING COLUMN / COLUMN SWITCH GEAR HARNESS
LIGHTING AND TURN SIGNAL SWITCH / BULKHEAD HARNESS, RIGHT TURN
LIGHTING AND TURN SIGNAL SWITCH / DIRECTIONAL INPUT
LIGHTING AND TURN SIGNAL SWITCH / BULKHEAD HARNESS, LEFT TURN
INSIDE LEFT REAR WHEEL ARCH / HIGH MOUNT STOP LIGHT HARNESS
HIGH MOUNT STOP LIGHT / HIGH MOUNT STOP LIGHT HARNESS
HIGH MOUNT STOP LIGHT SWITCH
LEFT COMPONENT PANEL / FLASHER UNIT
BEHIND HEATED REAR WINDOW SWITCH / HAZARD SWITCH
LOWER LEFT 'A' POST / BULKHEAD HARNESS
RIGHT FRONT TURN SIGNAL / LEFT FRONT TURN SIGNAL
LEFT FRONT TURN SIGNAL / LEFT FRONT TURN SIGNAL
RIGHT 'A' POST / ENGINE TO BULKHEAD HARNESS
RIGHT TAIL LIGHT UNIT / RIGHT STOP, TURN LIGHTS
ABOVE BRAKE (ABS) CONTROL MODULE / STOP LIGHT RELAY
LEFT TAIL LIGHT UNIT / LEFT STOP, TURN LIGHTS
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BEHIND LEFT TRUNK LID GAS STRUT SUPPORT / REAR BRAKE LT. WARNING CIRCUIT
BELOW LOWER LEFT A/C OUTLET / REARWARD HARNESS
BELOW LOWER LEFT A/C OUTLET / REARWARD HARNESS

GROUNDS

CODE	DESCRIPTION
LBG200	EYELET
LBG201	EYELET
LFG18L	EYELET
LFG18R	EYELET
RHG105L	EYELET
RHG111L	EYELET
RHG111R	EYELET

LOCATION / INTERFACE

LEFT 'A' POST FASCIA END PANEL / POWER GROUND LEFT 'A' POST FASCIA END PANEL / POWER GROUND TOP LEFT RADIATOR SUPPORT MOUNT / POWER GROUND TOP RIGHT RADIATOR SUPPORT MOUNT / POWER GROUND RIGHT REAR INNER WHEEL ARCH / POWER GROUND LEFT REAR INNER WHEEL ARCH / POWER GROUND RIGHT REAR INNER WHEEL ARCH / POWER GROUND