

Fluid level checks

ENGINE OIL SPECIFICATION

- ❗ Low quality or obsolete oils do not provide the protection required by modern, high performance engines.
- ❗ Failure to use an oil that meets the required specification could cause excessive engine wear, a build up of sludge and deposits and increased pollution. It could also lead to engine failure.
- ❗ Your vehicle's warranty may be invalidated if damage is caused by the use of unapproved engine oil.
- ❗ Do not use oil additives of any type as engine damage could occur. Use only specified lubricants.

Model	Specification
V8 Petrol engines	SAE 5W-20 meeting Jaguar specification WSS M2C925-A only.

Jaguar recommends:

Castrol EDGE Professional



TOPPING UP THE OIL

- ❗ Overfilling with oil could result in severe engine damage.
1. Unscrew the oil filler cap, see [145. ENGINE COMPARTMENT OVERVIEW](#).
 2. Add oil as indicated by the message centre display.
 3. Wait five minutes for the oil level to stabilise then re-check.

It is essential to use the correct specification oil, and to ensure it is suitable for the climatic conditions in which the vehicle is to be operated.

ENGINE OIL CONSUMPTION

A certain amount of oil consumption is normal. The rate of consumption will depend on the following:

- The quality and viscosity of the oil.
- Climatic conditions.
- The speed at which the engine is being operated.
- Road conditions.

Drivers should expect above normal consumption when the engine is new, and after running-in if high speeds are sustained.