



OBDII scanner
Vgate

Bluetooth signal

Android box remote

IR signal

IR emitter

Image shown on touch screen depends on the state of GVIF activation switch – ON will show TorquePro image – OFF will show OEM navigation image from DVD

Android Box with TorquePro App

5V DC (twisted pair)

5V DC (USB/mini-USB)

HDMI cable

HDMI to RCA converter

RCA cables

GVIF activation switch

GVIF remote sensor

"OEM cable"

IR signal

GVIF remote

TOBSUN EA15-5V
15W DC-DC CONVERTER
Input Output
12V 24V 5V 3A

12V-5V converter

12V DC (twisted pair)

GVIF

Cable supplied with GVIF

Navigation DVD Player

"OEM cable" new routing

"OEM cable" old routing

TorquePro image path

OEM navigation image path

Switched 12V power