| Voltage | State of the Battery's Charge |
|----------------|-------------------------------|
| 12.6 or higher | 100% |
| 12.5 | 90% |
| 12.42 | 80% |
| 12.32 | 70% |
| 12.2 | 60% |
| 12.06 | 50% |
| 11.9 | 40% |
| 11.75 | 30% |
| 11.58 | 20% |
| 11.31 | 10% |
| 10.5 or lower | Dead |

HOW TO TEST YOUR CAR'S VOLTAGE

While you can always take your car to a mechanic (or an oil change spot) to have