

CAUTION: The steering wheel contains two logic ground circuits that must remain separate. Do not connect or cross-switch the BO and BK circuits.

NOTE: Vehicles with Navigation – refer to Fig. 17.2 for CD Auto-Changer circuit.

1 → 6 / 1 II → 4 II	Fig. 01.1	7 → 49	Fig. 01.2	5 II → 48 II	Fig. 01.4	1 → 19 I	Fig. 02.1
		50 → 85	Fig. 01.3	49 E → 62 E	Fig. 01.5		

I Input — O Output — Signal Ground (SG) — D Serial and Encoded Communications — C CAN (Network) — S SCP Network

VARIANT: Premium ICE Vehicles
VIN RANGE: F00103 →
DATE OF ISSUE: October 1999