

11 = TRIGGER UNIT

12 = THROTTLE SWITCH

13 = COLD START RELAY

14 = ECU

16 = MAIN RELAY

17 = PUMP RELAY

19 = EGR = IF FITTED - CONTROL UNIT

20 = AXLE SOLENOID - ??

15 = BATTERY

D. JETRONIC

Fig. 10.129 Wiring diagram – fuel injection XJS – continued