

Radio wiring:

Red/white (thinner of the two) = ignition switch live in

Red/white (thicker of the two) = feed to aerial relay

Purple = permanent live for radio memory

Grey/red = illumination with sidelights

Speakers

Looking at the car loom as it pulls out from the dash, speaker wires starting at RHS of the domino plug as you look at the domino plug in the radio hole: RHS to LHS of plug:

Rear RHS speaker

Front RHS speaker

Front LHS speaker

Rear LHS speaker (these have little brown collars on the wires to distinguish them from the rear RHS wires)

The stripe on the car loom speaker wires goes to the positive terminal of the speakers (bigger terminal). NOTE that on the DIN plug short loom the striped is for the negative speaker terminal. SO at the domino plug the DIN loom striped speaker wires connect to the loom plain wires.