



VEHICLE MAINTENANCE CHECKLIST

SEDAN RANGE (4.0L NA / S/C and 6.0L V12) 1995 – 1997 MY

S,1897,SED

Date of Issue: 3/2000

S,1897,SED page 1 of 2

Owner _____ R.O. NO. _____ Date _____

VIN

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

 Odometer _____

Model (check one): XJ6 VDP XJR XJ12

Maintenance interval: every 7,500 mi. (12,000 km) or 6 months, whichever comes first. **(check one)**

	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
miles x 1,000	7.5	15	22.5	30	37.5	45	52.5	60
kilometers x 1,000	12	24	36	48	60	72	84	96

NOTE: Protect the interior and fenders of the vehicle before proceeding

ENGINE COMPARTMENT

Check engine and oil filter for leaks with engine running	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Automatic transmission – check / top up if necessary	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Brake fluid level – check / top up if necessary*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Engine coolant – check / top up; assure specific gravity**	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Power assisted steering fluid level – check / top up if necessary	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Windshield / headlight washer fluid level – check / top up if necessary	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cooling system hoses, pipes, unions – check for leaks, chafing, corrosion, cracks, security	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Cruise control vacuum hoses – check for leaks, chafing, cracks, security	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Air filter (4.0L NA) – replace				<input type="checkbox"/>				<input type="checkbox"/>
Air filter (4.0L S/C) – replace		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Drive belt s (except supercharger) – check / adjust				<input type="checkbox"/>				<input type="checkbox"/>
Supercharger drive belt – check / adjust	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Drive belt s (except supercharger) – replace								<input type="checkbox"/>
Supercharger drive belt – replace				<input type="checkbox"/>				
Radiator matrix and condenser – remove dirt accumulation	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Headlights – check / adjust aim	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Spark plugs – replace	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Visually check for any fluid leaks	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Intake air filter, normally aspirated – replace element			<input type="checkbox"/>			<input type="checkbox"/>		
Intake air filter, supercharged – replace element		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>

TRUNK

Battery electrolyte level – check / top up	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Spare tire – check pressure and general condition; check tread depth; record depth on page 2 ...	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* **Replace brake fluid every 2 years:** 2 year maintenance 4 year maintenance 6 year maintenance

** **Replace coolant every 4 years:** 4 year maintenance 8 year maintenance

continued on next page

