



VEHICLE MAINTENANCE CHECKLIST

All 1998 Models

\$,1898

Date of Issue: 3/2000

S,1898 page 1 of 1

Owner _____ R.O. NO. _____ Date _____

VIN

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Odometer _____

Model: XJ8 XJ8L VDP XJR XK8

Maintenance interval: every 10,000 mi. (16,000 km) or 12 months, whichever comes first.

Maintenance interval (check one)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
miles x 1,000	10	20	30	40	50	60	70	80	90	100
kilometers x 1,000	16	32	48	64	80	96	112	128	144	160

NOTE: Protect the interior and fenders of the vehicle before proceeding.

ENGINE COMPARTMENT

Brake fluid – check / top up as necessary*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Power assisted steering fluid level – check / top up if necessary	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Windshield washer fluid level – check / top up if necessary	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive belt – check belt tension wear indicator(s); replace belt(s) if necessary	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Visually check for any fluid leaks	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Intake air filter, normally aspirated – replace element			<input type="checkbox"/>			<input type="checkbox"/>			<input type="checkbox"/>	
Intake air filter, supercharged – replace element		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Fuel filter – replace						<input type="checkbox"/>				
Engine coolant – replace										— Every 4 years or 60,000 miles (96,000 kilometers) —
Spark plugs, normally aspirated – replace										<input type="checkbox"/>
Spark plugs, supercharged – replace						<input type="checkbox"/>				
Accessory drive belt – replace										<input type="checkbox"/>
Supercharger drive belt – replace				<input type="checkbox"/>				<input type="checkbox"/>		

TRUNK

Battery electrolyte level – check / top up	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Spare tire – check pressure and general condition; check tread depth, record depth below**	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

UNDERBODY

Engine oil – replace oil, filter and drain plug washer	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Brakes – inspect pads for wear; check rotor condition on pad change	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Axle shafts – lubricate universal joints	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Visually check for any fluid leaks	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

EXTERIOR

NOTE: The 6-year Corrosion (perforation) Inspection must be carried out at 12-month intervals starting at the date of the first retail sale.

Windshield wiper blade rubber insert(s) – replace	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Windshield wiper blade(s) and insert(s) – replace			<input type="checkbox"/>					<input type="checkbox"/>		
Tires – check pressure, tread depth and general condition; record tread depth below**	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Road test – record comments in the signature box below	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Replace brake fluid every 2 years: 2 year maintenance 4 year maintenance 6 year maintenance

** Tire tread depth: LH front _____ RH front _____ LH rear _____ RH rear _____ Spare _____

Comments: _____

Signature: _____