MAINTENANCE CHECKSHEET - F-TYPE [X152] - 2016MY



Maintenance must be carried out at intervals not to exceed 16,000 miles (26,000 km) or 1 year, whichever occurs first.

Should the vehicle have a high proportion of short journeys or operate in severe conditions, Jaguar recommends that the maintenance procedures be performed at intervals not to exceed 6 months.

MAINTENANCE INTERVAL	TIME (years)	1	2	3	4	5	6	7	8	9	10
	MILES (thousands)	16	32	48	64	80	96	112	128	144	160
	KILOMETERS (thousands)	26	52	78	104	130	156	182	208	234	260
Check operation of all lights, warning indicators, horn			•								
Check wiper blades for wear and wiper/washer operation			-		•						
Check/top up underhood fluid levels			•								
Check coolant protection			-								
Check for underhood/under vehicle fluid leaks			-	•	-				•		-
Check brake pad wear (disc condition on pad change)			-		-						
Check tires (including spare): - condition, pressure, tread depth - signs of uneven wear - correct size and type		•	•	•	•	•	•	•	•	•	•
Check EPB operation											
Renew engine oil and filter					•						
Reset Service Interval and Engine Oil Level indicators			-	•	-				•		-
Renew pollen filter			•								
Renew transfer case oil											
Renew air cleaner elements											
Renew spark plugs											
* Renew brake fluid		every 3 years regardless of mileage									
Renew secondary (supercharger) engine drive belt		every 6 years / 96,000 mi / 156,00 km**									
·		every 9 years or 144,000 mi / 234,000 km**									
★ Renew engine coolant		every 10 years or 160,000 mi / 260,000 km**									
* Fault lamps illuminated? If 'yes', use SDD for diagnosis/repair		•	•	•	•	•		•		•	•
Check for open Recall and/or Service Action campaigns			•								
Perform comprehensive road test and verify the following:											
interlock		 Transmission shifts up and down smoothly; SportShift/Jaguar Sequential Shift™ operation Check operation of Intelligent Stop/Start system 									

- Correct operation of fault lamps and instruments
- Condition and operation of seatbelts
- Steering column and seat adjustment operation
- Starter motor operates normally and engine starts easily
- Steering self-centers from left- and right-hand turns
- Vehicle does not pull or wander to one side
- Brakes operate smoothly without judder, noise, or pull to one side
- Check operation of Intelligent Stop/Start system
- Cruise control operation
- Climate control operation
- Inspect for undue vehicle noises
- Report any unusual features of vehicle condition and additional/remedial work required

^{*} labor cost not included in scheduled time

^{**} whichever occurs first