



VEHICLE MAINTENANCE CHECKLIST

All 1999 Models

S,1899

Date of Issue: 3/2000

S,1899 page 1 of 1

Owner _____ R.O. NO. _____ Date _____

VIN Odometer _____

Model: XJ8 XJ8L VDP XJR XK8

Maintenance interval: every 10,000 mi. (16,000 km) or 12 months, whichever comes first.

Maintenance interval (check one)	<input type="checkbox"/>												
miles x 1,000	10	20	30	40	50	60	70	80	90	100			
kilometers x 1,000	16	32	48	64	80	96	112	128	144	160			

NOTE: Protect the interior and fenders of the vehicle before proceeding

ENGINE COMPARTMENT

Brake fluid – check / top up as necessary*	<input type="checkbox"/>												
Power assisted steering fluid level – check / top up if necessary	<input type="checkbox"/>												
Windshield washer fluid level – check / top up if necessary	<input type="checkbox"/>												
Drive belt – check belt tension wear indicator(s); replace belt(s) if necessary	<input type="checkbox"/>												
Visually check for any fluid leaks	<input type="checkbox"/>												
Intake air filter, normally aspirated – replace element			<input type="checkbox"/>										<input type="checkbox"/>
Intake air filter, supercharged – replace element	<input type="checkbox"/>		<input type="checkbox"/>							<input type="checkbox"/>		<input type="checkbox"/>	
Fuel filter – replace													
Engine coolant – replace													— Every 4 years or 60,000 miles (96,000 kilometers) —
Spark plugs, normally aspirated – replace													<input type="checkbox"/>
Spark plugs, supercharged – replace													<input type="checkbox"/>
Accessory drive belt – replace													<input type="checkbox"/>
Supercharger drive belt – replace						<input type="checkbox"/>							<input type="checkbox"/>

TRUNK

Battery electrolyte level – check / top up	<input type="checkbox"/>												
Spare tire – check pressure and general condition; check tread depth, record depth below**	<input type="checkbox"/>												

UNDERBODY

Engine oil – replace oil, filter and drain plug washer	<input type="checkbox"/>												
Brakes – inspect pads for wear; check rotor condition on pad change	<input type="checkbox"/>												
Axle shafts – lubricate universal joints	<input type="checkbox"/>												
Visually check for any fluid leaks	<input type="checkbox"/>												

EXTERIOR

NOTE: The 6-year Corrosion (perforation) Inspection must be carried out at 12-month intervals starting at the date of the first retail sale.

Windshield wiper blade rubber insert(s) – replace	<input type="checkbox"/>												
Windshield wiper blade(s) and insert(s) – replace				<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Tires – check pressure, tread depth and general condition; record tread depth below**	<input type="checkbox"/>												
Road test – record comments in the signature box below	<input type="checkbox"/>												

* Replace brake fluid every 2 years: 2 year maintenance 4 year maintenance 6 year maintenance

** Tire tread depth: LH front _____ RH front _____ LH rear _____ RH rear _____ Spare _____

Comments: _____

Signature: _____