



Fig. 18

Measure and mark out the centres for the siren mounting bracket securing screw holes (Fig. 18).

- Mark the hole positions with a punch.

Drill holes 1/8 inch in diameter for the mounting bracket fixing screws.  
 Fit and align the bracket to the vehicle using the No. 8 screws supplied.  
 Fit and align the siren to the mounting bracket stud, using the nut and washer supplied.  
 Identify and displace the vehicle siren harness connectors (3, Fig. 17).  
 Connect the siren link lead to the siren harness.  
 Secure the harness neatly using the ratchet straps supplied.  
 Reposition the wheel arch front liner and secure in place with the four securing screws and the two lower securing nuts.  
 Refit the road wheel.  
 Remove the axle stands and lower the vehicle carefully to the ground.  
 Reconnect the negative battery terminal.  
 Refit the battery cover trim.  
 Refer to the operating instructions and carry out a validity and function check.  
 Adjust the motion detector to the required sensitivity.  
 Refit the right hand rear sideliner.  
 Close the boot lid.  
 Close the driver's door.